

Contents

Cable Kit Size	Top Fixings	Bottom Fixings	Screws (Wood fixing only)	Cable
2 m Kit	1	1	6	2 m

Wall-Mount Fittings

Step 1

Unscrew top fixing (A) and screw to wall.

Step 2

Screw part (B) onto part (A).

Step 3

Feed the cable through part (C) and into part (B), depressing the 'clutch' to allow cable entry.

Step 4

Attach part (C) to part (B) and tighten fully.

Step 5

Cut the cable to the required length (usually 20 - 25 mm less than distance between fixings).

Step 6

Unscrew part (F) and part (E) from part (D) N.B. Part (E) works on a reverse thread.

Step 7

Screw part (F) to the wall.

Step 8

Screw part (E) onto part (F) with 2 x turns anti-clockwise.

Step 9

Screw part (D) onto part (E) with half a turn.

Step 10

Feed the cable into part (D), depress the clutch to allow cable entry.

Step 11

Tension the cable by turning part (E) anti-clockwise whilst holding part (D) in place.

Step 12

Your cable kit is now ready to use.

Warnings

- Please choose fixings suitable for the surfaces you are attaching the cable kit to.
- If you are in any doubt, consult a qualified professional.
- Where stated, all measurements are approximate.