

Contents

Top Fixing (2 Parts)	Bottom Fixing (3 Parts)	Cable	Screws	Wall Plugs	Allen Key
1	1	4 m	2	2	1

Wall-Mount Fittings

Step 1

Unscrew top fixing, removing parts (B) and (C) from part (A).

Step 2

Screw part (A) to the wall.

Step 3

Screw part (B) onto part (A) and then screw part (C) onto part (B).

Step 4

Cut the cable to the required length.

Step 5

Unscrew bottom fixing, removing part (E) and (F) from part (D).

Step 6

Screw part (F) to the wall.

Step 7

Feed the cable through part (D).

Step 8

Thread spring (G) and cable holder (H) on the the cable.

Step 9

Screw in grubs screws (I) ensuring you leave 10 mm of cable free at the end.

Step 10

Screw part (E) onto part (F) and then screw part (D) onto part (E).

Step 11

Tension the cable by continuing to screw part (D) until suitable tension is achieved.

Step 12

Your cable kit is now ready to use.

Warnings

- Please choose fixings suitable for the surfaces you are attaching the cable kit to.
- If you are in any doubt, consult a qualified professional.
- Where stated, all measurements are approximate.